

Product Warranty

Virtual Industries, Inc.
PRODUCT WARRANTY
LIMITED 90 DAY WARRANTY

Above named company warrants to the original consumer purchaser that its PAC-VAC™ shall be free from defects in material and workmanship for a period of 90 days from the date of purchase. If a defect covered by this warranty occurs during the 90 day warranty period, return the unit to above named company for repair or replacement of the unit, at the option of the above named company. For the correct address and return authorization call:

1-800-530-8377 or (719) 572-5566

This warranty does not cover damage or malfunctions resulting from improper handling, accident, misuse, abuse, failure of electrical power, use with other products not manufactured by the above named company, damage while in transit for repairs, repairs attempted by any unauthorized person or agency, or any other reason not due to defects in materials or workmanship. This warranty is also void if the serial number has been altered, defaced or removed.

UNIT SERIAL NUMBER _____

THE ABOVE WARRANTIES FOR GOODS ARE IN LIEU OF ALL WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ABOVE NAMED COMPANIES LIABILITY IS LIMITED SOLELY TO THE REPAIR OR REPLACEMENT OF THE UNIT IN ITS SOLE DISCRETION, AND IN NO EVENT SHALL INCLUDE CONSEQUENTIAL COSTS, EXPENSES OR DAMAGES INCURRED BY THE PURCHASER, INCLUDING WITHOUT LIMITATION ANY DAMAGE TO PRODUCTS BEING HANDLED, EVEN IF THE ABOVE NAMED COMPANY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

THE ABOVE NAMED COMPANY shall have no obligation to enhance or update any unit once manufactured.

Some states do not allow limitations on how long any implied warranty lasts so the above limitations may not apply to you. Some states do not allow the exclusion or limitation or incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.



Virtual Industries, Inc.
2130 Victor Place
Colorado Springs, CO 80915
U.S.A.

www.virtual-ii.com
info@virtual-ii.com
Phone: 719-572-5566
FAX: 719-572-5504

8:00 A.M. to 4:30 P.M. Mountain Standard Time



8/10/22

OPERATING INSTRUCTIONS AND SPECIFICATIONS

PAC-VAC™

Battery Operated ESD Safe
Vacuum Handling Tool

Model No. V3200-CLN



Operation of the PAC-VAC™



Install the 9 volt battery

1. Connect the small diameter vacuum hose to the vacuum fitting on the front of the PAC-VAC™. Make sure the hose is pushed all of the way on. Connect the other end of the vacuum hose to the rear of the vacuum handle, again make sure the hose is pushed all of the way on.
2. Select a probe with a vacuum cup that is slightly smaller in diameter to the outline of the parts that you want to pick and place. Securely install it on the tapered end of the vacuum handle. Selecting a vacuum cup that is too large or too small will result in improper operation. Dust on the vacuum cup suction surface may also interfere with operation. Vacuum cups can be cleaned with Isopropyl Alcohol.
3. Install the 9 volt battery in the battery compartment on the back of the PAC-VAC™ body. Turn the ON/OFF switch to the ON position. The pump should now be running
4. To pick and place a part:
 - A. Gently place the vacuum cup on top of the part that you wish to pick up. The part should now be firmly grasped by the vacuum cup.
 - B. Move the part to where you want it.
 - C. Depress the button on the handle. The part should now be released.
5. Remember to turn the unit off when you are finished.

Specifications

ESD SAFE:

ELECTRICALLY CONDUCTIVE PLASTIC CASE
5 FEET OF 1/16" BLACK COILED ESD SAFE VACUUM HOSE
STATIC DISSIPATIVE PLASTIC NOZZLE

Hose color may vary. Vacuum hoses are available in straight or coiled custom lengths, please contact Virtual Industries to order (719) 572-5566. There are no returns or refunds on custom lengths.

VACUUM:

MINIMUM 16 INCHES OF MERCURY AT SEA LEVEL.

DIMENSIONS:

LENGTH	HEIGHT	WIDTH
4.6" (130mm)	1.1" (27mm)	2.4" (61mm)

WEIGHT:

24 OUNCES (680 GRAMS)

POWER REQUIREMENTS:

9 VOLT BATTERY

PAC-VAC VACUUM CUPS WITH PROBES OPTIONS

SET OF 9 VACUUM TIPS (VCS-9-B)



For technical assistance call toll free 1-800-590-5504

Tele: 719-572-5566

Fax: 719-572-5504

8:00 A.M. to 4:30 P.M. Mountain Standard Time